

Installation Manual

Multisealant A




1




Make sure the joint is free from dust, dirt and grease. Moisten the structure, if necessary.

3



Apply Multisealant A generously to the joint to prevent air bubbles.

2



If backing is applied, cut it slightly wider than the joint width and make sure that it is applied to the correct depth in the joint.

4



Smooth the joint with a damp spatula or filler knife.



Information



Virtual Reality



Augmented Reality

For use and for more information about an application, refer to the Mulcol documentation and local and international approvals. See the **Mulcol Fire Protection app** for the correct application in combination with fire resistance, or use our selector at www.mulcol.com
For professional use only.

MULCOL
INTERNATIONAL