


Coil Roofing nailer ESSVE CRN 15/45



Coil Roofing nailer ESSVE CRN 15/45

Pos	Art. Nr.	Name	Pos	Art. Nr.	Name	Pos	Art. Nr.	Name	Extras:		
101		DEFLECTOR BOLT(3M2353)	214		TRIGGER UNIT	427		FIXED PIN			
102		DEFLECTOR	215		SPRING	428		O - RING			
103		MUFFLER	216		LOCATING WHEEL	429		SAFETY COVER			
104		RUBBER PAD	217		HINGE POINT	430		FLAT WASHER			
105		HEX.SOC.HD.BOLT	218		SPRING	431		HEX.SOC.HD.BOLT	Service kits:		
106		GUIDE COVER	219		RING	432		MAGNET	901059		Service kit
107		PROTECTIVE CUSHION	301		GUN BODY	433		SAFETY GUIDE	901061		Feeding kit
108		CAP	302		C - RING	434		SPRING PIN	901067		Adjustable support
109*		SEAL	303		FILTER	435		SAFETY SPRING	901063		Driver kit
110		COMPRESSION SPRING	304		END CAP	436		SAFETY B UNIT	901065		Door latch set
111*		O - RING	305		O - RING	437		ADJUST AXIE	901069		Trigger valve kit
112		HD.VALVE PISTON	306		AIR PLUG	438		SAFETY COVER	901195		Trigger Switch kit
113*		O - RING	401		NOSE PIECE	439		ADJUST ROD			
114*		COLLAR	402		O - RING	440		O - RING			
115		PACKING	403		O - RING	441		SAFETY			
116		CYLINDER PRESS RING	404		FEED FINGER	442		E - RING			
117		PISTON RING	405		HEX.SOC.HD.BOLT	443*		SAFETY A UNIT			
118*		O - RING	406		FEED PISTON	444		COUNTER SUNK SCREW			
119*		DRIVER UNIT	407		PIN FEED PISTON	445		PIN			
120		CYLINDER	408*		FEED FINGER SPRING	446		MAGAZINE COVER			
121		O - RING	409		PU RETAINER	447		SPRING BASE A			
122		CYLINDER SPACER	410*		O - RING	448		PULL SPRING			
123		O - RING	411*		O - RING	449*		SPACER			
124		CYLINDER RING	412		FEED PISTON SPRING	450		MAGAEING POST			
125*		BUMPER	413		FEED-BUMPER	451		TAP BOLT			
201		O - RING	414		FEED PISTON CAP	452		MAGAZINE CASE			
202		O - RING	415		BOLT ASSY	453		O - RING			
203		PLUNGER CAP	416		FIRST STOPPER FINGER	454		SPRING RETAINER			
204		VALVE PLUNGER	417		SECOND STOPPER FINGER	455		MAGAZINE PROTECTIVE CUSHION			
205		O - RING	418		SPRING	456		MAGAZINE GUIDE COVER			
206		O - RING	419		GUIDE BLOCK SPRING	457		BOLT ASSY			
207		SPRING	420		PIN-NAIL STOP	458		POSITIONING SHEET			
208		PLUNGER	421		DOOR	459		SAFETY SPRING			
209		O - RING	422		LATCH SPRING	460		ADJUSTING PLATE-A			
210		TRIGGER VALVE HEAD	423		DOOR LATCH	461		ADJUSTING PLATE-B			
211		SPRING PIN	424		SPRING PIN						
212		SPRING PIN	425		DOOR SHAFT PIN						
213		SPRING PIN	426*		GUIDE BLOCK						

