

Expansion Shell

Expansion shells are used for fixing single-sided shuttering or similar structures in rock, concrete or comparable load-bearing ground. When installing expansion shells, please consult the separate installation instructions available on demand.

Article No.	Bar Ø [mm]	Borehole Ø [mm]	Weight [kg/m]
15 F 2128	15	32 – 34	0.20
15 F 2135	15	35 – 38	0.30
15 F 2184	15	35 – 37	0.39
20 F 2136	20	43 – 48	0.48
20 F 2137	20	51 – 53	0.68
26 E 2221	26.5	61 – 63	1.14
26 E 2137	26.5	51 – 53	0.60

Please ask for installation instructions

